BEFORE ENGINE START			BEFORE	TAXI	DEPARTURE BRIEFING			DESCENT			
1	Preflight Inspection	COMPLETE	1	Comm Radios	CHECK/SET	Departing Runway	Direction of Departure	1	Altime	ter SET	
2	Weight and Balance	WITHIN LIMITS	2	Altimeter	SET	Type of Takeoff	Crosswind Correction	2	Aux Pu	np ON	
3	Passengers	BRIEFED	3	*Navigation	CONFIGURED	RESPONSE TO ENGI	NE FAILURE OR FIRE	з	Lig	nts AS REQUIRED	
4	Seat & Seatbelts	SECURE	4	HDG Bug	WIND	Before Rotation	Below 1,000'AGL	4	Autop	lot AS REQUIRED	
		ł	5	ALT Bug	SET	1,000-2,000' AGL	Above 2,000' AGL	5	Fuel Selec	tor FULLEST TANK	
	ENGINE START		6	Transponder	SET		· · · · · · · · · · · · · · · · · · ·	6	Park Bra	ke OFF	
1	Park Brake	VERIFY SET	7	Autopilot	TEST, DISCONNECT		TAKEOFF	7	Seats & Seatbe	Its SECURE	
2	Key	INSERT	8	Flight Controls	FREE & CORRECT	1 Fuel Pump	s ON				
3	Master	ON	9	Fuel Selector	SWITCH TANKS	2 Flap	s POS 1		BEFOR	E LANDING	
4	Lanes A & B	ON	10	Taxi Light	ON	3 Light	s AS REQUIRED	1	Engine Gaug	es GREEN	
5	Main Pump	ON	11	Flaps	UP	4 Fuel Selecto	r PROPER TANK				
6	EFIS BKUP & EFIS 1	BOTH ON				5 Trir	n NEUTRAL				
7	Strobe Lights	ON		TAXII	NG	6 Transponde	r SET	1	Fla		
8	Fuel Selector	LOWEST TANK	1	Brakes	СНЕСК	7 Seats & Seatbelt	s SECURE	2	Lig		
9	Throttle	CRACKED	2	Instruments	CHECK	8 Canop	y LOCKED	3	Aux Pu	•	
10	Hobbs	RECORD				9 Departure Briefin	g COMPLETE	4	Pitot H		
11	ECU BKUP	ON		RUN-				5	Transpon	ler SET	
12	Check lane lig	hts, PSI > 40.5	1	Park Brake	SET	CL	MB		SHU	TDOWN	
13	ECU BKUP	OFF	2	Throttle	4000 RPM	1 Throttl	e FULL FORWARD	1	Park Brake SE		
14	Propeller	CLEAR	3	Lanes A & B	CYCLE	2 Flap	s UP	2		0 RPM	
15	Starter	ENGAGE	4	Lane Lights	EXTINGUISHED	3 Engine Gauge	s GREEN	3		OFF EXCEPT EFIS BKU	
16	Throttle	2500 RPM	5	Aux Pump	ON	4 Light	s AS REQUIRED	4		CORD	
17	*Oil Pressure	RISING	6	Main Pump	OFF				EFIS BKUP OF		
18	Lane Lights	EXTINGUISHED	7	Throttle	IDLE CHECK	CRUISE		6			
19	Main Bus Volts	> 13.8V	8	Main Pump	ON	1 Throttl	e CRUISE RPM	7		MOVED	
20	EFIS 2	ON	9	Throttle	2500 RPM	2 Fuel Selecto	r FULLEST TANK		Rey RE		
21	Avionics & Autopilot	BOTH ON	10	Engine Gauges	GREEN	3 Aux Pum	o OFF		Do N	lot Fold!	
22	GTN	INITIALIZE	11	Breakers	ALL IN	4 Engine Gauge	s GREEN				

	ENGINE FAILURE IN FLIGHT			ENGINE FIRE DURING START			ELECTRICAL FIRE			ALTERNATOR FAILURE			
1	Airspeed	72 KIAS	1	Starter	RELEASE	1 M	aster Switch	OFF	1	Effected Lan	e CYCLE		
2	Landing Area	LOCATE	2	Fuel Selector	OFF	2	Lanes A & B	REMAIN ON	2	IF WARNING LIG	IT PERSISTS		
3	Fuel Selector	SWITCH TANKS	3	Fuel Pumps	OFF	3 Electric	cal Switches	OFF	3	ECU Backu	o ON		
4	ECU Backup	ON	4	Throttle	IDLE	4 Fire	Extinguisher	AS NEEDED	4	EFIS Backu	o ON		
5	Fuel Pumps	ON	5	Lanes A & B	OFF	5 Fre	esh Air Vents	OPEN	5	Non-Essential Equipmen	t MINIMUM		
6	Throttle	MIDDLE	6	Master Switch	OFF	6	6 IF FIRE IS EXTINGUISHED				:		
7	Master Switch	VERIFY ON	7	Fire Extinguisher	RETRIEVE	7 PERFC	7 PERFORM PRECAUTIONARY LANDING			DUAL ALTERNATO			
8	Starter	ENGAGE	8	Cabin	EVACUATE	8 IF I	8 IF FIRE DOES NOT EXTINGUISH		1	ECU Backu			
9	• *IF ENGINE STARTS				9 PER	9 PERFORM EMERGENCY LANDING			EFIS Backu				
10	Aux Pump	OFF			RE IN FLIGHT				3	Main Battery Voltag			
11	LAND AT NEAR	EST SUITABLE AIRPORT	1		CLOSE		LOW OIL P		4	Non-Essential Equipmer			
12	IF ENGINE	DOES NOT START	2	Fresh Air Vents	OPEN	1		MINIMUM REQUIRED	5	Aux Pum			
13	Transponder	SQUAWK 7700	3		IDLE					ENGINE RUN TI	/IE: 30 MINS		
14	Comm Radio	121.5 OR AS REQUIRED	4		OFF		3 LAND AS SOON AS PRACTICAL			EFIS SYSTEM F	AILURE		
15	Transmit	DECLARE EMERGENCY	5		OFF		4 IF OIL TEMPERATURE IS HIGH			MAINTAIN STRAIGHT	& LEVEL FLIGHT		
16	16 PERFORM EMERGENCY LANDING		6	Fuel Selector OFF EXECUTE EMERGENCY DESCENT		5 L	5 LAND AS SOON AS POSSIBLE			EFIS 1 & 2 0	FF		
				8 WHILE DESCENDING			HIGH OIL PRESSURE			EFIS Backup 0	FF		
1			9		SQUAWK 7700	1	Throttle	MINIMUM REQUIRED	4	WAIT 3 SE	ONDS		
2	Seatbelts Fuel Selector	TIGHT	10	Transponder Comm Radio	121.5 OR AS REQUIRED	2 LA	2 LAND AS SOON AS PRACTICAL		5	EFIS 1 & 2 0	N		
			10		DECLARE EMERGENCY				6	EFIS Backup 0	N		
3	Fuel Pumps	OFF	12				LOW FUEL PRESSURE			7 LAND AS SOON AS PRACTICAL			
4	Lanes A & B Canopy	AJAR	12			1 Fuel	I Quantity	СНЕСК					
6		AJAR AS NEEDED	13	13 PERFORM EMERGENCY LAN		2 Fue	l Selector	SWITCH		SPINS			
0	Flaps Master Switch	AS NEEDED		EMERGEN	CY DESCENT	3 Fu	el Pumps	ON	1	Power II	LE		
		-	1	Throttle	IDLE	4 IF	PRESSURI	E REMAINS LOW	2	Ailerons N	EUTRAL		
8	Touchdown		2	Bank	30-45°	5	Throttle	MINIMUM REQUIRED	3	Rudder 0	PPOSITE SPIN		
	Brakes	APPLY	3	Airspeed	VNE (135 KIAS)	6 L4	AND AS SO	ON AS POSSIBLE	4	Elevator F	ORWARD		
10	Cabin	EVACUATE			-					02/22/	2024 Sling 912is. Rev 19		

			23	23 RIGHT WING		52 FINAL WALK AROUND			PASSENGER BRIEFING			
6	6		24	General Condition	СНЕСК	53 W	heel Chocks	REMOVED		s	SEAT BELTS & HARNESSES SEAT POSITION	
-	6	1	25	Flap	SECURE	54	Tie Downs	REMOVED		А	ALL ENVIRONMENTAL CONTROLS	
			26	Hinges, Pushrods	CHECK CONDITION	55	Tire Inflation	CHECK		~	ACTION IN CASE OF DISCOMFORT	
			27	Aileron	PROPER MOVEMENT	56	Fuel Caps	IN PLACE		F	FIRE EXTINGUISHER	
	3		28	Wing Tip & Lights	SECURE	57	Cowl Plugs	REMOVED		E	EXITS & EVACUATION EMERGENCY/SURVIVAL KIT	
	PREF	LIGHT	29	Leading Edge	UNDAMAGED	58	Oil Door	CLOSED			TRAFFIC	
1	FLIG	HT DECK	30	Fuel Vent	UNOBSTRUCTED					Т	TALKING	
2	Parking Brake	SET	31	Fuel Sump	DRAIN & CHECK		RISK AS	SESSMENT		Y	YOUR QUESTIONS?	
3 F	Req'd Documents	ON BOARD	32	Wheel Pant	CHECK CONDITION	Р	PILOT					
4	Lanes	OFF	33	NOSE	SECTION	A	AIRCRAFT				V SPEEDS	
5	Master	ON	34	Cowling	SECURE	enV	ENVIRONM	ENT		Vr	45 KTS	
6	EFIS 1	ON	35	Gascolator	DRAIN & CHECK	E	EXTERNAL	PRESSURES		Vs0	40 KTS	
7	Flaps	DOWN	36	Oil & Coolant	CHECK LEVELS					Vs1	45 KTS	
З	Fuel Quantity	Fuel Quantity CHECK	37			PILOT ASSESSMENT				Vfe	85 KTS	
G3X VERIFY		VERIFY DATABASES		Burp	AS NEEDED	I ILLNESS				Vx	65 KTS	
10	Lights	CHECK	38	Prop & Spinner	CHECK CONDITION	М	MEDICATIO	N		Vy	72 kts	
11	EFIS 1	OFF	39	Air Intakes	CHECK CONDITION	S	STRESS			Va	91 kts	
12	Master	OFF	40	Wheel Pant	CHECK CONDITION	A	ALCOHOL			Vno	110 kts	
13	Windscreen	CLEAN	41	LEF	TWING	F	FATIGUE		Vne 135 kts		135 kts	
14		42		General Condition	CHECK	E EATING OR EMOT		EMOTION			72 kts	
			43	Fuel Sump	DRAIN & CHECK				_			
	General Condition	CHECK	44	Wheel Pant	CHECK CONDITION			LIGHT	GUN	SIGNALS		
16	Antennas	SECURE	45	Fuel Vent	UNOBSTRUCTED	SI	GNAL TYPE	AIRCRAFT O	N GRO	DUND	AIRCRAFT IN FLIGHT	
17	*Left Static	CLEAR	46	Pitot Mast	CHECK CONDITION		Steady G	ireen Cleared fo	r take	off	Cleared to land	
18	Horizontal Stab	SECURE	47	Leading Edge	UNDAMAGED		Flashing G	ireen Cleared	for tax	ci	Return for landing	
19	Vertical Stab	SECURE	48	Wing Tip & Lights	SECURE		Steady	Red Sto	р		Give way, continue circling	
20	Elevator	PROPER MOVEMENT	49	Aileron	PROPER MOVEMENT					way	Airport unsafe, do not land	
21	Trim Tab	CHECK CONDITION	50	Hinges, Pushrods	CHECK CONDITION					Flashing White Return to starting		point
22	Rudder	CHECK CONDITION	51	Flap	SECURE	Alternating Red and Green Exercise extre		eme c	aution	Exercise extreme caution		
23	*Right Static	CLEAR	L					ח	οN	lot Fo	02/22/2024 Sling 912	

